

Please read all instructions before setting the unit up.

- 1) Take the unit out of the box.
- 2) Set it in a level location on your bench or the area to be controlled. The unit turns on and off by the amount of mist on the screen (leaf) so position it where water will hit the screen without obstruction.
- 3) Connect the blue cable to the <u>two AC screws</u> on the transformer and the black cable to your 24-volt AC solenoid. Make sure connections are tight.
- 5) Make sure the screen moves up and down freely.
- 6) Turn weight in until leaf does not stay at the top.
- 7) Screw weight out (counter clockwise) a quarter turn at a time until screen comes to the top.
- 8) Push screen down and keep a finger on it as the screen comes up, if it stops, turn the weight counter-clockwise a quarter turn. And try again until the screen comes all the way up.
- 9) Plug the 24-volt transformer into a <u>surge protector</u> that is plugged into a 120VAC outlet. Caution: watering may start when the unit is plugged in. The green light will be lit anytime the transformer is plugged in. The blue light indicates when power is being sent to energize the solenoid.
- 8) You can also get some adjustment by moving the unit closer to or further from the mist nozzles.

Make sure that you monitor the unit during the first day of use. Fans blowing on the screen or leaves touching the screen could cause the unit to remain in an on or off position.



Troubleshooting

Stuck off – back weight (counter clockwise) out a quarter turn at a time until it stops getting stuck. It's best to do this with the water off and a dry screen.

Stuck On - make sure Leaf is getting enough mist to weigh it down. If the screen is wet, screw weight clockwise a quarter turn at a time until the screen goes down. Keep an eye on the leaf to make sure it comes back up when

No power – Is the transformer light lit? Yes – make sure you are wired to the AC screws and not ground. Look under leaf and check that the blue cord is plugged into the board. While there, check that the black cord is also plugged into the board. Check that voltage from transformer is around 24-28 volts. If not check voltage of outlet. If none of that works, the board probably took a surge and needs replacement.

Transformer light not lit? – check outlet for power. If there is power, transformer is blown. This is normally due to a short on the solenoid wire.

If you have questions please call Phytotronics at (314) 770-0717

Limited Warranty

Phytotronics®, Incorporated ("we") warrant to the original purchaser ("you") that the product or system accompanying this warranty (the "product") will be free from defects in material and workmanship existing at the time of manufacture and appearing within two (2) years from the date of original purchase. This warranty applies only so long as the product is stored, installed, operated and maintained in accordance with our recommendations, and when used under proper and normal use. THIS WARRANTY SHALL BE EXCLUSIVE AND, TO THE EXTENT PERMITTED BY LAW, SHALL BE IN LIEU OF ANY OTHER WARRANTIES, WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT IMPLIED WARRANTIES MAY NOT BE DISCLAIMED, THE DURATION OF SUCH WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS EXPRESSLY LIMITED TO THE TWO YEAR PERIOD OF DURATION OF THIS LIMITED WARRANTY. In certain circumstances, some states do not allow imitations on how long an implied warranty lasts, so the above limitation may not apply to you.

When this Limited Warranty does not apply

This warranty does not cover claims resulting from <u>power surge</u>, <u>lightning</u>, failure to follow instructions on installation and use, neglect, misuse, accident, modifications, alterations, acts of God, vandalism, misapplication or repairs made by you or others, use of unauthorized attachments, use on a current or voltage other than specified, or overloading.

Your remedies

If a covered defect appears during the warranty period, we will, (at our sole option), repair or replace the defective product at no charge for service or parts, provided that the product is delivered at your expense to our authorized service center. Parts and/or replacement product supplied under this warranty may be new or rebuilt at our option. Any product which is repaired or any replacement product will be covered under this warranty for the remainder of the one year period or for 90 days after repair or replacement, whichever is longer. THIS IS YOUR EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY OR OF ANY IMPLIED WARRANTY OR OF ANY OTHER OBLIGATION ARISING BY OPERATION OF LAW OR OTHERWISE.

What is not covered by the Limited Warranty

The warranty does not include reimbursement for the expenses of labor, transportation, installation, removal or any other expenses which may be incurred by you. For instructions on how to obtain warranty ser-vice, call 314-770-0717 or write to Phytotronics® Customer Service, 13688 Rider Trail North, Earth City, Missouri 63045.

IN NO EVENT SHALL WE BE LIABLE OR RESPONSIBLE FOR PUNITIVE, EXEMPLARY, SPECIAL, INCIDENTAL ORCONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, LOSS OF CROP, REVENUES OR SAV-INGS ARISING OUT OF THE BREACH OR PERFORMANCE OF ANY WARRANTY OR THE USE OR INABILITY TO USE THIS PRODUCT FOR ANY PURPOSE WHATSOEVER.

YOUR EXCLUSIVE COMPENSATION FOR LOSS OR DAMAGE ARISING FROM PURCHASE, USE, REPAIR OFREPLACEMENT OF ANY PRODUCT SHALL BE LIMITED TO AN AMOUNT EQUAL TO THE PURCHASE PRICE OF THEPRODUCT. THIS LIMITATION OF LIABILITY SHALL BE APPLICABLE TO ANY CLAIMS PRESENTED TO US REGARDLESSOF THE LEGAL THEORY FORMING THE BASIS OF SUCH CLAIM, AND WHETHER SUCH THEORY INVOLVES NEGLIGENCE, CONTRACTUAL LIABILITY, FAILURE OF REMEDY OR OTHERWISE.

In certain circumstances, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

13688 Rider Trail North Earth City, MO 63045 (314) 770-0717 Fax (314) 506-4587